






RINSE SPRUES IN WARM SOAPY WATER TO REMOVE ANY MOULD RELEASE BEFORE ASSEMBLY.





PARTS CAN BE FOUND AS **RESIN** AND ON THE **SULTANATE FRONTLINE SQUADRONS** SPRUES

