




SCAN THIS CODE OR VISIT
WILDWESTEXODUS.COM
FOR ASSEMBLY GUIDES AND MORE!

WEX991399029



RED OAK POST OFFICE

PART OF THE



@WILDWESTEXODUS



@WARCRADLESTUDIOS



WARNING! NOT A TOY. AGE 14+
HOBBY GAMING PRODUCT
CONTAINS SMALL PARTS



ACHTUNG! KEIN SPIELZEUG. ALTER 14+
HOBBY SPIELPRODUCT
ENTHÄLT KLEINE TEILE



PRECAUCIÓN! NO ES UN JUGUETE EDADES. 14+
PRODUCTO DE HOBBY
CONTIENE PIEZAS PEQUEÑAS



ATTENTION! PAS UN JOUET. ANS 14+
PRODUIT DE JEU HOBBY
CONTIENT DE PETITES PIÈCES


THIS PRODUCT CONTAINS MEDIUM DENSITY FIBREBOARD (CLASS E1)




WARCRADLE STUDIOS IS A TRADING NAME OF WAYLAND GAMES LIMITED. WILD WEST EXODUS IS A TRADEMARK OF WAYLAND GAMES LIMITED.
ILLUSTRATIONS AND DESIGNS ARE COPYRIGHT © 2018 WAYLAND GAMES LIMITED. ASSEMBLED IN THE UK.




Parts may need careful removal from the MDF boards with a scalpel, and light sanding of any rough edges. We recommend testing assembling sections before permanently gluing together.




- Glue 2x A5 together under each window (on part A12).
- Insert C6 then A3, making sure the notch at the bottom of A3 faces towards you.
- Push C6 as far left as possible.




- Glue a second A3 on the other side of the doorway, notch facing the same way as Step 1.
- Hold C7 & A15 together and push into place.
- Assemble the back door (A17) in the same way (back wall labelled A16).



- Connect C11, C12, C1 & C2 to B4. Horizontal line on C1 and C2 should be facing B4 as shown.
- 2x C3, C4 & C5 attach where shown.
- Glue A2, B2 & C8 in place on B4.



- Combine A12, B1, B3 & A16.




- Combine 2x A10, A13 & A14 as shown.
- Connect 2x A6 to A14.
- Attach parts C14 and then C13 in the three places shown.
- Connect porch to front wall (A12).



- Connect C10 to front wall (A12).
- Combine parts labelled A8.
- Combine parts labelled A11.
- Combine parts labelled A18 & B8.
- Connect framework together, then attach to building.



- Connect porch roof (C15)
- Connect A9 to C15 where shown.



- Connect 2x A1 to C15.
- Connect 'Post Office' or 'Doctor' sign (A7/C9) to 2x A1.
- Glue A4 in place.



- Connect B5 & B7 to the left side wall (B1).
- Glue B6 to B7 & B5.
- Slot roof into the building (do not glue).